

THORN

7 TEST E1/3, E3/8		Green Led / Grün Led	
Manual Start/ Manueller Start Function Test : Monthly, 1 min Duration Test : Annually, 1H/3H 3H/8H		Led ON	- AC Mode - Battery connected
		Led OFF	- Emergency Mode - Test Mode - Battery disconnected
8 TEST E1/3T, E1/3D, E1/3BC E3/8T, E3/8D, E3/8BC	Function test/ Funktionstest : Every 7 days Duration Test/ Dauertest : Annually	Manual Start/ Manueller Start	
Green LED		Status	
		System OK	
		Duration Test	
		Function Test	
		Inhibit Mode (E1/3D, E1/3BC, E3/8D, E3/8BC) (Switching into DALI Inhibit Mode via controller)	
Red LED		Status	
		Led Module Failure	
		Battery disconnected	
		Battery failure	
Green Led and Red Led On		Status	
		Battery operation (Emergency Mode) or after Rest Mode	
		Address Identification Mode (E1/3D, E1/3BC, E3/8D, E3/8BC)	



VOYAGER STAR MSC

Battery Exchange

9a If the backup does not extend to the declared duration, the battery has to be replaced.

9b

9c

9d

9e

9f

9g

9h

E1/3
E1/3T → 59013928
E1/3D 3.2V-2.0Ah Li-FePO4
E1/3BC

E3/8
E3/8T → 59013929
E3/8D 3.2V-3.8Ah Li-FePO4
E3/8BC

(EN) Instructions for installation and operation!

The installation and commissioning of the luminaire as well as any modification to the luminaire may only be performed by authorized personnel (qualified electrician). National installation regulations must be observed. Before any work on the appliance is done, it must be disconnected from mains. **Hot plug-in is not an option and may cause damage to the lamp or luminaire!** The manufacturer is not liable for damages resulting from improper or faulty installation or operation or from unauthorized modifications to the luminaire. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similarly qualified person.

Caution, risk of electric shock!
Specifications are subject to change without notice! If you have questions, please contact the manufacturer.

(DE) Hinweise für die Montage und den Betrieb!

Die Montage und Inbetriebnahme der Leuchte sowie jede Veränderung an der Leuchte darf nur von autorisierten Fachkräften (qualifizierter Elektriker) durchgeführt werden. Die nationalen Errichterbestimmungen sind zu beachten. Vor jeder Arbeit an der Leuchte ist diese vom Netz zu trennen. **Hot Plug-in ist nicht möglich und kann zu Schäden an der Leuchte führen!** Der Hersteller haftet nicht für Schäden, die aus fehlerhafter Montage, aus unsachgemäßem Betrieb oder unautorisierten Veränderungen an der Leuchte resultieren. Die Lichtquelle dieser Leuchte darf nur vom Hersteller oder einem von ihm beauftragten Servicetechniker oder einer vergleichbar qualifizierten Person ausgetauscht werden.

Vorsicht, Gefahr eines elektrischen Schlags!
Technische Änderungen vorbehalten! Bei Fragen wenden sie sich an den Hersteller.

MAN_VSTR_MSC_2520

NAME	SPECIFICATIONS/ SPEZIFIKATIONEN
VOYAGER STAR MSC E1/3 S VOYAGER STAR MSC E1/3T S VOYAGER STAR MSC E1/3D S VOYAGER STAR MSC E1/3BC S	1/3H, Manual test/ Manueller test 1/3H, AutoTest 1/3H, DALI 1/3H, basicDim Wireless (Casambi)
VOYAGER STAR MSC E3/8 S VOYAGER STAR MSC E3/8T S VOYAGER STAR MSC E3/8D S VOYAGER STAR MSC E3/8BC S	3/8H, Manual test/ Manueller test 3/8H, AutoTest 3/8H, DALI 3/8H, basicDim Wireless (Casambi)
VOYAGER STAR MSC ECD VOYAGER STAR MSC ECP P VOYAGER STAR MSC ELP P VOYAGER STAR MSC ECC	CENTRAL, 100-240V DALI CENTRAL, 220-240V PLC CENTRAL, 48V DC PLC CENTRAL, 100-240V BASIC
(EN) Mounting instructions Important notices. Please, read first! Keep the instructions safe! Specifications are subject to change without notice! If you have questions, please contact the manufacturer.	(DE) Montageanleitung Wichtige Hinweise. Bitte zuerst lesen! Anleitung aufbewahren! Technische Änderungen vorbehalten! Bei Fragen wenden Sie sich an den Hersteller.

